



PTA 22 HAND PALLET TRUCK INSTRUCTIONS FOR ADJUSTING THE WIDTH OF FORKS

1. The forks are secured with 3 bolts each. An allen key is used to loosen and tighten these. The allen key is kept in two plastic brackets underneath the A-frame of the pallet truck as shown on photo.

2. Loosen all bolts and slide forks to achieve the desired width across them.



IMPORTANT

3. First tighten the single bolt at the fork heels. While doing this, check that forks are straight and parallel.



4. Only then tighten the two top bolts on each fork.

Check all bolts are secured tight.

The pallet truck is now ready to be used in its new width configuration.

5. All bolts must be secured tight in order to prevent them from coming loose during usage.

